


40 288 000 **TENSO GLASS/SOAP DISH HOLDER**



PRODUCT DESCRIPTION

- Colour: Chrome
- for soap dish
- without soap dish
- GROHE Long-Life finish



Pure Freude
an Wasser



40 288 000 **TENSO GLASS/SOAP DISH HOLDER**

SPARE PARTS, January 2000 – now

1: Fixing set (Spare part-nr. 40056000)

Zu diesem Produkt gibt es
keine Ersatzteile mehr.

For this product there are no
spare parts anymore.